




ZigBee Gateway Controller

09.288WNZG.04160



Important: Read All Instructions Prior to Installation

Function introduction



WiFi Reset switch: press and hold down for 10S then release, the blue WiFi indicator will go off and go on again, WiFi setting will be factory reset.

Note: When the hub is configured to home router, use the button to reset WiFi setting to enable to control directly through the hub network again.

Product Data

Radio protocol	ZigBee PRO
Operation Frequency	2.4GHz
Power Supply	12VDC
Operating temperature	0-40°C
Relative humidity	8% to 80%
Dimensions	110x85x24.2mm


- This ZigBee gateway controller works with ZigBee lighting devices and remote controllers.
- Free APP is available for IOS or Android smart phones or tablets.
- Can be controlled by smart phones or home network.
- Waterproof grade: IP20.

Safety & Warnings


- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.

Wiring diagram

Method 1: Configure the gateway to your home network, then connect your smart phone with your home network router



Method 2: Connect your smart phone directly with the gateway



Operation

1. Download "Easy Home" APP from "APP Store" or "Google Play" by searching "Easy Home – Smart Home".
2. If the gateway has been configured to a router, then connect your cell phone to your router network. If the gateway has not been configured to a router, then connect your cell phone to the gateway network directly.
(Password: 0123456789)
3. Open the Easy Home application and operate according the application manual.