





Important: Read All Instructions Prior to Installation

Function introduction

Click or to choose the zone, Touch the sliders to dim CCT color(if choose CCT color zone) or RGB color(if choose RGB color zone)



Front side



Product Data

| | DC Version | AC Version |
|-----------------------|--------------|--------------|
| Output Signal | RF signal | RF signal |
| Power Supply | 12-24VDC | 100-240VAC |
| Power consumption | 20 mA | 20 mA |
| Operating temperature | 0-40°C | 0-40°C |
| Relative humidity | 8% to 80% | 8% to 80% |
| Dimensions | 86x86x29.1mm | 86x86x29.1mm |


DO 1/- --!--

- Touch sensitive
- · Glass interface(white & black)
- Compatible with all universal series RF receivers, radio frequency: 869.5/434MHz
- · Control RGB+CCT color
- Control 4 zone of RF receiver synchronously and separately
- Waterproof grade: Ip20

Safety & Warnings


- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.

Wiring diagram



AC Version

A O \ / - -- ! - --




Back side

Operation

- 1. Do wiring the wall panel & RF receiver according to wiring diagram (please refer to the instruction of RF receiver that you would like to pair with)
- 2. Power on, then touch the button 🖒 to turn on the controller, indicator of the controller turned blue

Pair with RF receiver



Note: an only can pair with LED CCT color lighting.

nly can pair with LED RGB color lighting.

Operate the remote after pairing

Click the paired zone number/numbers, then touch the slider or the other buttons to do the controlling

Built-in 10 color changing modes are as follows:

Mode 1: Any two colors of RGB mix fade-in & fade-out

Mode 2: RGB three colors mix fade-in & fade-out

Mode 3: RGB three colors mix fade-out & fade-in

Mode 4: RGB flash


Mode 5: RGB three colors fade-in & fade-out successively

Mode 6: RGB three colors fade-in successively

Mode 7: RGB three colors fade-out successively

Mode 8: RGB three colors jump changing successively

Mode 9: R&B two colors mix fade (R in B out), then G fade-in, then R&B mix fade (R out B in), then G fade-out Mode 10: B fade-out, then G&B mix fade (G out B in), then R&G mix fade (R out G in), then R fade-in



Installation

