RF Wireless Single Color/Dual Color Remote

Important: Read All Instructions Prior to Installation

Function introduction

On/Off

Control the receiver's channel 1 and channel 3.
Press and hold down to adjust warm white between 0%-100%
Only work with dual color, it's useless for single color.

Press and hold down to increase light intensity smoothly

Control the receiver's channel 2 and channel 4.
Press and hold down to adjust cool white between 0%-100%
Only work with dual color, it's useless for single color.

Press and hold down to decrease light intensity smoothly

6 zones control.
Click to choose the zone,
Press and hold down to turn on/off the zone

Front side

Note:Before the first use, please remove the protective film on the battery.

Back side

Product Data

Output	RF signal
Operation Frequency	868/915/434MHz
Power Supply	3V(1xCR2025 battery)
Operating temperature	0-40°C
Relative humidity	8% to 80%
Dimensions	136.3x38.9x10.7mm

- Control 6 zones of receivers separately
- Single color/dual color controller
- Compatible with all universal series RF receivers
- 1 receiver can be paired by max 8 different remote controls.
- Waterproof grade: IP20

Safety & Warnings

- This device contains a button lithium battery that shall be stored and disposed properly.
- DO NOT expose the device to moisture.

Pair with RF receiver

RF LED Receiver

Learning Key

Step 1: Do wiring the RF receiver according to wiring diagram(please refer to the instruction of RF receiver that you would like to pair with.

Step 2: Click the "**Learning Key**" button on RF receiver to set it into pairing status

Step 3: Choose and click a zone number(e.g. zone 4)

Step 4: Click any of the four buttons ✳ ✳ ☼ ☼ , LED lights connected with the RF receiver flicker once means the receiver is paired with zone 4 successfully.

Note: one receiver can be paired with max 8 remote controls.

Switch between single color mode or dual color mode:

Single color mode: Choose a zone(e.g. zone **4**), press and hold down **4** & ✳ together about 5-10 seconds, then zone **4** was under single color mode. Under this model, ☼ and ☼ will not working.

Dual color mode: Choose a zone(e.g. zone **4**), press and hold down **4** & ☼ together about 5-10 seconds, then zone **4** was under dual color mode.

If you use multiple receivers, you have two choices:

Option 1: have all the receivers in the same zone, like zone 1

RF LED Receiver
Learning Key

RF LED Receiver
Learning Key

Zone 1

(((

RF remote

Option 2: have each receiver in a different zone, like zone 1, 2, 3 or 4

RF LED Receiver
Learning Key

RF LED Receiver
Learning Key

RF LED Receiver
Learning Key

Zone 1

Zone 2

Zone 3

(((

RF remote