2-Key Zigbee Push Button Smart Switch









Important: Read All Instructions Prior to Installation


Function introduction


On button, short press to turn on





"Reset" Kev: for zigbee network pairing, touchlink or factory reset the device





Product Data

Input Voltage	Output Voltage		Output Current	Minimum Load			Max. Number of Parallel Connected Load	Size(LxWxH)
100-240VAC	100-240VAC		10A max	7W LED(no neutral without bypass) 3W LED(no neutral with bypass) No minimum load requirement with neutra		9	86x86x42.4mm	
Compatible Load Types								
Load Symbol		Loa	Load Type		Maximum Load	Remarks		
→		LED lamps with transformers			690W @ 230V 345W @ 110V	Due to variety of LED lamp designs, maximum number of LED lamps is further dependent on power factor result when connected to the switch.		
→		LED drivers		690W @ 230V 345W @ 110V	Maximum permitted number of drivers is 690W divided by driver nameplate power rating.			
-\[\bar{\pi}\-		Incandescent lighting, HV Halogen lamps		2300W @ 230V 1150W @ 110V				
		Low voltage halogen lighting with electronic transformers		690W @ 230V 345W @ 110V				

ZigBee Clusters the device supports are as follows:

Input Clusters

- 0x0003: Identify 0x0004: Groups • 0x0000: Basic 0x0005: Scenes 0x0006: On/off
- 0x0702: Simple Metering 0x0008: Level Control 0x0b04: Electrical Measurement • 0x0b05: Diagnostics

Output Clusters

- 0x0019: OTA
- · ZigBee push button AC switch based on latest ZigBee 3.0 protocol
- 100-240VAC wide input and output voltage, can work under no neutral wiring and with neutral wiring, self-adaptive
- Supports resistive loads, capacitive loads or inductive loads
- 1 channel output, max. load 10A
- Enables to control ON/OFF of connected light source
- Supports energy metering, real time energy consumption can be monitored
- ZigBee device that supports Touchlink commissioning
- Can be controlled by zigbee gateway, zigbee remote and local push buttons
- Can directly pair to a compatible ZigBee remote via Touchlink without coordinator
- · Supports self-forming zigbee network without coordinator and add other devices to the network
- Supports find and bind mode to bind a ZigBee remote
- Supports zigbee green power and can bind max. 20 zigbee green power remotes
- Compatible with universal ZigBee gateway products
- With push switch input, can be controlled by universal AC push switches
- Standard size, can be compatible with existing EU standard frames, and installed into standard size wall box
- Radio Frequency: 2.4GHz
- · Waterproof grade: IP20

Safety & Warnings


- DO NOT install with power applied to device.
- DO NOT expose the device to moisture.

Operation

- 1.Do wiring according to connection diagram correctly.
- 2. This ZigBee device is a wireless receiver that communicates with a variety of ZigBee compatible systems. This receiver receives and is controlled by wireless radio signals from the compatible ZigBee system.
- 3. Zigbee Network Pairing through Coordinator or Hub (Added to a Zigbee Network)
- Step 1: Remove the device from previous zigbee network if it has already been added to, otherwise pairing will fail. Please refer to the part "Factory Reset Manually".

Step 2: From your ZigBee Controller or hub interface, choose to add lighting device and enter Pairing mode as instructed by the controller.

Step 4: Connected light will blink 5 times and then stay solid on, then the device will appear in your controller's menu and can be controlled through controller or hub interface.



Step 3: Reset power of the device from master breaker to set it into network pairing mode (connected light flashes twice slowly), 15 seconds timeout, repeat this step.


4. TouchLink to a Zigbee Remote


Step 1: Method 1: Short press "Reset" button 4 times (or reset power of the device 4 times from master breaker) to start Touchlink commissioning immediately under any circumstances, 180S timeout, repeat this step.

Method 2: Reset power of the device from master breaker, Touchlink commissioning will start after 15S if it's not added to a zigbee network, 165S timeout. Or start immediately if it's already added to a network, 180S timeout. Once timeout, repeat this step.

Step 2: Bring the remote or touch panel within 10cm of the lighting device.

Step 3: Set the remote or touch panel into Touchlink commissioning, please refer to corresponding remote or touch panel manual to learn how.





Note: 1) Directly TouchLink (both not added to a ZigBee network), each device can link with 1 remote.


- 2) TouchLink after both added to a ZigBee network, each device can link with max. 30 remotes.
- 3) Control with both gateway and remote, add remote and device to network first then TouchLink.
- 4) After TouchLink, the device can be controlled by the linked remotes.

5. Removed from a Zigbee Network through Coordinator or Hub Interface



From your ZigBee controller or hub interface, choose to delete or reset the lighting device as instructed. The connected light blinks 3 times to indicate successful reset.


6. Factory Reset Manually



Step 1: Short press "Reset." key for 5 times continuously or reset power of the device from master breaker for 5 times continuously if the "reset" key is not accessible.

7. Factory Reset through a Zigbee Remote (Touch Reset)

Note: Make sure the device already added to a network, the remote added to the same one or not added to any network.



Step 1: Short press "reset" button 4 times (Or reset power of the device from master breaker) to start TouchLink Commissioning, 180 seconds timeout, repeat this step.


8. Find and Bind Mode

Note: Make sure the device and remote already added to the same zigbee network.

Step 2: Set the remote or touch panel (target node) into find and bind mode, and enable it to find and bind initiator, please refer to corresponding remote or touch panel manual.


Step 3: There shall be indication on the remote or touch panel that it bind the device successfully and can control it then.





Step 1: Short press "Reset." button 3 times (Or reset power of the device (initiator node) 3 times from master breaker) to start Find and Bind mode (connected light flashes slowly) to find and bind target node, 180 seconds timeout, repeat this step.


9. Learning to a Zigbee Green Power Remote



Step 1: Short press "Reset." button 4 times (Or reset power of the device 4 times from master breaker) to start Learning mode (connected light flashes twice), 180 seconds timeout, repeat this step.


Note: Each device can learn to max. 20 zigbee green power remotes.

10. Delete Learning to a Zigbee Green Power Remote



Step 1: Short press "Reset." button 3 times (Or reset power of the device 3 times from master breaker) to start delete Learning mode (connected light flashes slowly), 180 seconds timeout, repeat this step.

11. Setup a Zigbee Network & Add Other Devices to the Network (No Coordinator Required)



Step 1: Short press "Reset." button 4 times (Or reset power of the device 4 times from master breaker) to enable the device to setup a zigbee network (connected light flashes twice) to discover and add other devices, 180 seconds timeout, repeat this step.

Step 2: Set another device or remote or touch panel into network pairing mode and pair to the network, refer to their manuals

Step 3: Pair more devices and remotes to the network as you would like, refer to their manuals.

Step 4: Bind the added devices and remotes through Touchlink so that the devices can be controlled by the remotes, refer to their manuals.

Note: 1) Each added device can link and be controlled by max. 30 added remotes.

2) Each added remote can link and control max. 30 added devices.

12. OTA

The device supports firmware updating through OTA, and will acquire new firmware from zigbee controller or hub every 10 minutes automatically.

Wiring Diagram

Notes for the diagrams:


- L terminal for live lead
- N terminal for neutral lead
- S terminal for push switch


Controlled by a push switch:

Once connected with a push switch, click the push switch to switch ON/OFF

(1) 2-Wire Connection With No Neutral Lead Single push switch wiring


Multiple push switches wiring for multiple control points






The Bypass is a device designed to work with the push button smart switch. It should be used in case of connecting LED bulbs or energy saving compact fluorescent lamps. The Bypass prevents flickering of the LED lights and glowing of the turned off compact fluorescent lamps. In the case of 2-wire connection, the Bypass allows to reduce minimum power of load required by the switch for correct operation. The Bypass provides powering of the switch in case of controlling the low loads of minimum power down to 3W (for cosp>0.5).

(2) 3-Wire Connection With Neutral Lead Single push switch wiring



Multiple push switches wiring for multiple control points





2-Wire connection without neutral lead

3-Wire connection with neutral lead

