# 30W ZigBee CCT LED Driver(constant current)












Important: Read All Instructions Prior to Installation

**Function introduction** 




#### **Product Data**

Output	Selectable Current	250mA	300mA	350mA	400mA	450mA	500mA	550mA	600mA	
	DC Voltage Range	8-55V	8-55V	8-55V	8-55V	8-55V	8-55V	8-54V	8-50V	
	Selectable Current	650mA	700mA	750mA	800mA	850mA	900mA	950mA	1000mA	
	DC Voltage Range	8-46V	8-43V	8-40V	8-37V	8-35V	8-33V	8-31V	8-30V	
	Rated Power	30W max.								
Input	Voltage Range	200-240V AC								
	Frequency Range	50/60Hz								
	Power Factor (Typ.)	> 0.9 @ 230VAC								
	Total Harmonic Distortion	THD ≤ 12% (@ full load / 230VAC)								
	Efficiency (Typ.)	83% @ 230VAC full load								
	AC Current (Typ.)	0.17A @ 230VAC								
	Inrush Current (Typ.)	COLD START 8A max. at 230VAC								
	Leakage Current	< 0.5mA /230VAC								
Control	Dimming Interface	Zigbee 3.0								
	Dimming Range	0.1%-100%								
	Dimming Method	Amplitude dimming (PWM dimming under 1%)								
	Dimming Curve	Logarithmic/ Linear								
Environment	Working Temp.	-20°C ~ +45°C								
	Max. Case Temp.	85°C (Ta="45°C")								
	Working Humidity		10% ~ 95% RH non-condensing							
	Storage Temp. & Humidity		-40°C ~ +80°C, 10% ~ 95% RH							

Protection	Short Circuit	Yes, auto recovery after fault removed			
	Over Voltage	Yes, auto recovery after fault removed			
	Over Temperature	Yes, auto recovery after fault removed			
Safety&EMC	Safety Standards	ENEC EN61347-1, EN61347-2-13 approved			
	Withstand Voltage	I/P-O/P: 3.75KVAC			
	EMC Emission	EN55015, EN61000-3-2, EN61000-3-3			
	EMC Immunity	EN61547, EN61000-4-2,3,4,5,6,8,11, surge immunity Line-Line 1KV			
Others	MTBF	189400H, MIL-HDBK-217F @ 230VAC at full load and 25 ambient temperature			
	Dimension	170*53.4*28mm (L*W*H)			

Dips to set the operation current



1 2 3 4 650mA • O O O 700mA • O O 750mA • O • O 950mA ●●●O 1000mA ●●●●

- Dimmable LED driver for tunable white, ZigBee device based on ZigBee 3.0 protocol
- Max. output power 30W total, 2 channels 250-1000mA constant current output

1 2 3 4

- Dips to select multi operation current
- Class II power supply, full isolated plastic case
- · Built-in active PFC function, high power factor and efficiency
- Amplitude dimming, deep and smooth dimming to 0.1%, flicker free
- Enables to control ON/OFF, light intensity and CCT of connected CCT LED lights
- ZigBee end device that supports Touchlink commissioning
- Can directly pair to a compatible ZigBee remote via Touchlink
- Supports find and bind mode to bind a ZigBee remote
- •Supports zigbee green power and can bind max. 20 zigbee green power remotes
- Compatible with universal ZigBee gateway products
- Compatible with universal CCT ZigBee remotes
- Waterproof grade: IP20, suitable for indoor LED lighting applications
- 5 years warranty

## Safety & Warnings

- DO NOT install with power applied to device.
- DO NOT set operation current with power applied to device.
- DO NOT expose the device to moisture.

## **Wiring Diagram**



#### Operation

1.Do wiring according to connection diagram correctly.

2. This ZigBee device is a wireless receiver that communicates with a variety of ZigBee compatible systems. This receiver receives and is controlled by wireless radio signals from the compatible ZigBee system.

#### 3. Zigbee Network Pairing through Coordinator or Hub (Added to a Zigbee Network)

**Step 1**: Remove the device from previous zigbee network if it has already been added to, otherwise pairing will fail. Please refer to the part "Factory Reset Manually".

**Step 2**: From your ZigBee Controller or hub interface, choose to add lighting device and enter Pairing mode as instructed by the controller.

**Step 3**: power on the device, it will be set into network pairing mode (connected light flashes twice slowly), the network pairing mode will last until the device is added to a zigbee network.




**Step 4**: Connected light will blink 5 times and then stay solid on, then the device will appear in your controller's menu and can be controlled through controller or hub interface.

## 4. TouchLink to a Zigbee Remote

**Step 1: Method 1**: Short press "Prog" button (or re-power on the device) 4 times to start Touchlink commissioning immediately, 180S timeout, repeat the operation.


**Method 2**: If the device is already added to a network, it will be set into Touchlink commissioning immediately, 180S timeout. Once timeout, re-power on the device to set it into touchlink commissioning again.



Note: 1) Directly TouchLink (both not added to a ZigBee network), each device can link with 1 remote.

- 2) TouchLink after both added to a ZigBee network, each device can link with max. 30 remotes.
- 3) To control by both gateway and remote, add remote and device to network first then TouchLink.
- 4) After TouchLink, the device can be controlled by the linked remotes.

## 5. Removed from a Zigbee Network through Coordinator or Hub Interface



From your ZigBee controller or hub interface, choose to delete or reset the lighting device as instructed. The connected light blinks 3 times to indicate successful reset.

#### 6. Factory Reset Manually

**Step 1**: Short press "Prog." key for 5 times continuously or re-power on the device for 5 times continuously if the "Prog." key is not accessible.



Step 2: Connected light will blink 3 times to indicate successful reset.


Note: 1) If the device is already at factory default setting, there is no indication when factory reset again .

2) All configuration parameters will be reset after the device is reset or removed from the network.

### 7. Factory Reset through a Zigbee Remote (Touch Reset)


**Note:** Make sure the device already added to a network, the remote added to the same one or not added to any network.

Step 1: Re-power on the device to start TouchLink Commissioning, 180 seconds timeout, repeat the operation.




#### 8. Find and Bind Mode

**Step 1**: Short press "Prog." button 3 times (Or re-power on the device (initiator node) 3 times) to start Find and Bind mode (connected light flashes slowly) to find and bind target node, 180 seconds timeout, repeat the operation.




## 9. Learning to a Zigbee Green Power Switch

**Step 1**: Short press "Prog." button 4 times (Or re-power on the device 4 times) to start Learning to GP switch mode (connected light flashes twice), 180 seconds timeout, repeat the operation.




#### 10. Delete Learning to a Zigbee Green Power Switch

**Step 1**: Short press "Prog." button 3 times (Or re-power on the device 3 times) to start delete Learning to GP switch mode (connected light flashes slowly), 180 seconds timeout, repeat the operation.



## 11. Setup a Zigbee Network & Add Other Devices to the Network (No Coordinator Required)

**Step 1**: Short press "Prog." button 4 times (Or re-power on the device 4 times) to enable the device to setup a zigbee network (connected light flashes twice) to discover and add other devices, 180 seconds timeout, repeat the operation.



Note: 1) Each added device can link and be controlled by max. 30 added remotes.

2) Each added remote can link and control max. 30 added devices.

## 12. ZigBee Clusters the device supports are as follows:

#### Input Clusters

•0x0000: Basic •0x0003: Identify •0x0004: Groups •0x0005: Scenes •0x0006: On/off

• 0x0008: Level Control • 0x0300: Color Control • 0x0b05: Diagnostics

### **Output Clusters**

• 0x0019: OTA

#### 13. OTA

The device supports firmware updating through OTA, and will acquire new firmware from zigbee controller or hub every 10 minutes automatically.

#### **Product Dimension**

